



Ref. No.	Parts No.	Description	XS1/XS1B
1	256-83310-70-93	FRONT FLASHER LAMP ASS'Y	2
2	256-83330-75-93	REAR FLASHER LAMP ASS'Y, left	1
	256-83340-75-93	REAR FLASHER LAMP ASS'Y, right	1
3	183-83312-70-00	. LENS, flasher	2
	211-83332-75-00	. LENS, flasher	2
4	183-83333-71-00	. SCREW, lens fitting ...	8
5	183-83313-70-00	. GASKET, flasher lens .	4
6	256-83311-70-00	. BULB, flasher (12V-25W) (183-83311-70)	4
7	90170-08031-00	NUT	4
8	92903-08100-00	WASHER, spring	4
9	173-83350-70-00	FLASHER RELAY ASS'Y	1
10	92503-06010-00	SCREW, pan head	1
11	92903-06100-00	WASHER, spring	1
12	256-83318-00-00	STAY, flasher	2
13	256-83341-00-00	DAMPER	2
14	91503-06018-00	Pin, clevis	2
15	90468-12007-00	CLIP, tension bar (102-25375-00)	2
16	90201-06058-00	WASHER, special (6.5-18-1.6) (101-24187-00)	2
17	248-21635-00-00	NUT, rear fender	2
18	90201-12190-00	WASHER, rear cushion (12-27-2.0) (122-22243-00)	2
19	97303-08018-00	BOLT	2
20	92903-08100-00	WASHER, spring	2
21	256-84313-01-00	WIRE, earth (160L)	2
22	256-83336-01-00	CORD (350L)	1
23	256-83346-00-00	CORD (350L)	1