




Ref. No.	Parts No.	Description	XS1/XS1B/XS2/TX65			
1	306-24730-01-00	DOUBLE SEAT ASS'Y ...	1	1	1	1
	366-24730-01-00	DOUBLE SEAT ASS'Y ...				1
1-1	256-24731-00-00	SEAT COVER	1	1	1	1
2	256-24728-00-33	BRACKET, seat 1	1	1	1	1
3	256-24738-00-33	BRACKET, seat 2	1	1	1	1
4	256-24748-00-33	BRACKET, seat 3	1	1	1	1
5	97301-06012-00	BOLT	6	6	6	6
6	92903-06100-00	WASHER, spring	6	6	6	6
7	214-24724-00-00	DAMPER, seat	5	5	5	5
8	256-24718-00-00	BRACKET, seat under ..	1	1	1	1
9	97301-06010-00	BOLT	1	1	1	1
10	92903-06100-00	WASHER, spring	1	1	1	1
11	90201-06038-00	WASHER, plain	1	1	1	1
12	90249-04068-00	PIN, seat fitting (214-24727-00)	1	1	1	1
13	90508-10012-00	SPRING, seat (214-24758-00)	1	1	1	1
14	214-24776-00-33	LEVER, seat	1	1	1	1
15	256-24754-00-00	HOOK	1	1	1	1
16	91501-06010-00	PIN, clevis	1	1	1	1
17	90468-10050-00	CLIP (156-83525-00) ...	1	1	1	1
18	95303-08600-00	NUT	1	1	1	1
19	92903-08200-00	WASHER, plain	3	3	3	3
20	92903-08100-00	WASHER, spring	3	3	3	3
21	256-24734-00-00	HANDLE, seat	1	1	1	1
22	97301-08018-00	BOLT	2	2	2	2