



FRONT WHEEL TX650A/XS650B/C




Ref. No.	Part Number	Description	A	B	C
1	341-25111-01-00	HUB, front.....	1	1	1
2	341-25104-00-00	SPOKE SET.....	1s	1s	1s
	341-25196-90-00	. SPOKES, inner.....	1s	1s	1s
	341-25197-90-00	. SPOKES, outer.....	1s	1s	1s
3	[94135-19345-00]	TIRE, front (3.50-19-4PR).....	1	1	1
4	94235-19034-00	TUBE (3.50-19).....	1	1	1
5	94418-19145-00	RIM.....	1	1	1
6	94325-19027-00	BAND, rim (2.50-19)	1	1	1
7	371-25847-00-00	COVER, housing.....	1	1	1
8	92501-08015-00	SCREW, pan head...	3	3	3
9	92903-08100-00	WASHER, spring.....	3	3	3
10	90560-17126-00	SPACER.....	1	1	1
11	152-25115-00-00	SPACER, flange.....	1	1	1
12	93306-30306-00	BEARING (6303RS)	1	1	1
13	341-25149-00-00	CLUTCH, meter.....	1	1	1
14	341-25846-00-00	RETAINER, clutch meter.....	1	1	1
15	341-25137-00-00	RING, stop.....	1	1	1
16	90201-25286-00	WASHER, plats (B/C)	1	1	
17	341-25135-01-00	GEAR, drive.....	1	1	1

Tires (size/nominal pressure) | Front: 3.50H-19/230psi / Rear: 4.00H-18/260psi





Ref. No.	Part Number	Description	A	B	C
18	90201-25490-00	WASHER, plate	1	1	1
19	93105-45017-00	OIL SEAL (SDO-45-56-6)	1	1	1
20	341-25190-01-00	HOUSING, gear unit (341-25191-01)	1	1	1
21	306-25138-00-00	GEAR, meter	1	1	1
22	102-18416-00-00	SHIM (6.2-9.50.8) ...	1	1	1
23	306-25136-00-00	BUSHING	1	1	1
24	341-25181-01-00	SHAFT, wheel	1	1	1
25	91401-30030-00	PIN, cotter	1	1	1
26	93306-30301-00	BEARING (B6303)	1	1	
	93306-30307-00	BEARING (B6303) (C)			1
27	90387-17433-00	COLLAR (341-25183-00)	1	1	1
28	93102-28022-00	OIL SEAL (SD-28-47-7)	1	1	1
29	341-25118-00-00	COVER, dust	1	1	1
30	92901-14200-00	WASHER, plain	1	1	1
31	90171-14020-00	NUT, castle (90171-14006)	1	1	1



Tires (size/nominal pressure) Front: 3.50H-18/23psi / Rear: 4.00H-18/78psi