


Ref. No.	Part Number	Description	A	B
1	584-27111-00-00	STAND, main (447-27111-02)	1	1
2	90109-10288-00	BOLT	2	2
3	90185-10035-00	NUT, u.	2	2
4	90506-50064-00	SPRING	1	1
5	99999-01242-00	STAND, side	1	1
	341-27311-01-00	STAND, side	1	1
	[90506-23147-00]	SPRING, tension ...	1	1
	95301-08700-00	NUT	1	1
	90109-08034-00	BOLT	1	1
	447-27311-06-00	STAND, side. (B)		1
6	90109-08185-00	BOLT	1	1
7	95303-08900-00	NUT, slotted	1	1
8	91401-20020-00	PIN, cotter.	1	1

TX650A/XS650

9	90507-25003-00	SPRING, side stand	1	1
	90507-29009-00	SPRING, side stand. (B)		1
10	341-27314-02-00	STOPPER, side stand	1	1
	371-27114-00-00	STOPPER	(B)	1
11	1T3-27410-00-33	FOOTREST ASS'Y, left	1	1
12	1T3-27420-00-33	FOOTREST ASS'Y, right	1	1
13	341-27451-00-00	FOOTREST 3	2	2

TX650A/XS650B




Ref. No.	Part Number	Description	A	B
14	27423-00-00	COVER, footrest left	1	1
15	341-27413-00-00	COVER, footrest right	1	1
16	90508-20023-00	SPRING	2	2
17	90243-08006-00	PIN	2	2
18	90701-06042-00	WASHER, plate	2	2
19	256-27414-00-00	DAMPER, rubber 1	4	4
20	90201-10437-00	WASHER, rear cushion	4	4
21	92903-10100-00	WASHER, spring	4	4
22	90176-10013-00	NUT, cap	4	4

TX650A/XS650

23	447-27430-01-00	REAR FOOTREST ASS'Y, left	1	1
24	447-27440-01-00	REAR FOOTREST ASS'Y, right	1	1
25	447-27431-00-00	FOOTREST, rear left	1	1
26	447-27441-00-00	FOOTREST, rear right	1	1
27	447-27433-00-00	COVER, rear footrest	2	2
28	91501-06035-00	PIN, clevis	2	2
29	90209-18070-00	WASHER	2	2
30	91401-16015-00	PIN, cotter	2	2
31	90201-13501-00	WASHER, plate	2	2
32	90185-12046-00	NUT, u	2	2

TX650A/XS650B



Ref. No.	Part Number	Description	A	B
33	533-27211-01-93	PEDAL, brake	1	1
34	447-27212-01-00	SHAFT, brake pedal	1	1
35	90506-23046-00	SPRING (341-27216-00)	1	1
36	93700-06004-00	NIPPLE, grease.	1	1
37	447-27231-02-00	ROD, brake	1	1
38	90240-08012-00	PIN, w/hole.	1	1
39	90201-08083-00	WASHER, plate	1	1
40	91401-20015-00	PIN, cotter.	1	1

TX650A/XS650

41	90501-10245-00	SPRING (180-27226-00)	1	1
42	90259-12008-00	PIN (156-27237-00)	1	1
43	90179-06176-00	NUT	1	1
44	97321-06025-00	BOLT, hexagon.	1	1
45	92903-06100-00	WASHER, spring	1	1
46	90170-06184-00	NUT, adjusting	1	1
47	90153-06008-00	BOLT, special	1	1
48	90201-13502-00	WASHER.	2	2

TX650A/XS650B