





Ref. No.	Part Number	Description	DEF
1	256-81625-10-00	CONDENSER.....	1
2	92501-06008-00	SCREW, pan head.....	2
3	92903-06100-00	WASHER, spring.....	2
4	584-82508-40-00	MAIN SWITCH ASS'Y.....	1
5	533-82517-00-00	WASHER, special.....	2
6	98503-05015-00	SCREW, pan head.....	2
7	1A0-83350-70-00	FLASHER RELAY ASS'Y.....	1
8	168-82540-00-00	NEUTRAL SWITCH ASS'Y.....	1
9	90430-11034-00	GASKET (136-82543-00).....	1
10	168-82542-10-00	CAP.....	1

XS650D


11	533-82530-00-00	STOP SWITCH ASS'Y.....	1
12	341-82503-01-00	SWITCH, alarm.....	1
13	447-82531-00-00	WIRE, lead.....	1
14	447-81970-10-00	RECTIFIER ASS'Y.....	1
15	92903-08100-00	WASHER, spring.....	1
16	95301-08700-00	NUT, hexagon.....	1
17	371-84708-02-00	CHECKER, lamp.....	1
18	447-81940-10-00	STARTER SWITCH ASS'Y.....	1
19	92503-06015-00	SCREW, pan head.....	1
20	92903-06100-00	WASHER, spring.....	1

XS650D



Ref. No.	Part Number	Description	DE
21	256-81615-00-00	WIRE, lead	1
22	1A0-83395-03-00	FLASHER CANCELLING UNIT (1A0-83395-01)	1
23	1J7-84308-00-00	RESERVE LIGHTING UNIT ASS'Y	1
24	92503-06018-00	SCREW, pan head	2
XS650D			
25	92903-06100-00	WASHER, spring	2
26	92901-06600-00	WASHER, plate	2
27	1J7-81911-01-00	RESISTOR	1
28	97301-06012-00	BOLT	1
29	92903-06100-00	WASHER, spring	1

XS650D



SEE GRIDS J1, J2 FOR SERVICE DATA.

Ref. No.	Part Number	Description	DEF
1	256-81325-10-00	CONDENSER.....	1 1
2	92501-06008-00	SCREW, pan head.....	2 2
3	92903-06100-00	WASHER, spring.....	2 2
4	2F0-82508-50-00	MAIN SWITCH ASS'Y.....	1 1
5	533-82517-00-00	WASHER, special.....	2 2
6	98501-05016-00	SCREW, pan head.....	2 2
7	2F0-83350-70-00	FLASHER RELAY ASS'Y.....	1 1
8	136-82540-01-00	NEUTRAL SWITCH ASS'Y.....	1 1
9	90430-11034-00	GASKET (136-82543-00).....	1 1
10	533-82530-00-00	STOP SWITCH ASS'Y.....	1 1
11	447-81970-10-00	RECTIFIER ASS'Y.....	1 1

XS650E/E006501~

12	92903-08100-00	WASHER, spring.....	1 1
13	95301-08700-00	NUT, hexagon.....	1 1
14	371-84708-02-00	CHECKER, lamp.....	1 1
15	447-81940-10-00	STARTER SWITCH ASS'Y.....	1 1
16	92503-06015-00	SCREW, pan head.....	1 1
17	92903-06100-00	WASHER, spring.....	1 1
18	256-81615-00-00	WIRE, lead.....	1 1
19	1A0-83395-03-00	FLASHER CANCELLING UNIT (1A0-83395-02).....	1 1
20	1T3-84308-00-00	RESERVE LIGHTING UNIT ASS'Y	1 1
21	92503-06018-00	SCREW, pan head.....	2 2
22	92903-06100-00	WASHER, spring.....	2 2
23	92901-06600-00	WASHER, plate.....	2 2

XS650E/E006501~/F