




No.	Number	Description	Qty.
1	256-81625-10-00	CONDENSER.....	1
2	92501-06008-00	SCREW, pan head.....	2
3	92903-06100-00	WASHER, spring (92901-06100)	2
4	2G2-82508-50-00	MAIN SWITCH/STEERING LOCK ASS'Y	1
5	97301-06016-00	BOLT, hexagon	2
6	92901-06600-00	WASHER, plate.....	2
7	2F0-83350-70-00	FLASHER RELAY ASS'Y	1
8	136-82540-01-00	NEUTRAL SWITCH ASS'Y (136-82540-00)	1
9	90430-11034-00	. GASKET (136-82543-00)	1
10	533-82530-00-00	STOP SWITCH ASS'Y	1
11	447-81970-10-00	RECTIFIER ASS'Y.....	1
12	92903-08100-00	WASHER, spring (92901-08100)	1
13	95301-08700-00	NUT, hexagon	1
14	2M0-84708-01-00	CHECKER, lamp	1
15	447-81940-10-00	STARTER SWITCH ASS'Y.....	1
16	92503-06015-00	SCREW, pan head (92501-06015)	1
17	92903-06100-00	WASHER, spring (92901-06100)	1
18	256-81615-00-00	WIRE, lead.....	1
19	1A0-83395-03-00	FLASHER CANCELING UNIT (1A0-83395-02)	1
20	1T3-84308-00-00	RESERVE LIGHTING UNIT ASS'Y	1
21	92503-06018-00	SCREW, pan head (92501-06018)	2
22	92903-06100-00	WASHER, spring (92901-06100)	2
23	92901-06600-00	WASHER, plate.....	2