



Ref. No.	Part Number	Description	Qty.
1	341-12111-04-00	VALVE, intake (341-12111-02)...	2
2	341-12121-01-00	VALVE, exhaust.....	2
3	256-12116-01-00	SEAT, valve spring	4
4	90501-42286-00	SPRING (447-12114-00)	4
5	90501-29284-00	SPRING (447-12113-00)	4
6	341-12119-02-00	SEAL, valve stem oil.....	4
7	256-12117-02-00	RETAINER, valve spring (256-12117-01)	4
8	341-12118-00-00	LOCK, valve spring retainer.....	8
9	306-12151-00-00	ARM, valve rocker (256-12151-00)	4
10	90149-08098-00	SCREW, valve adjusting (583-12159-00)	4
11	90170-08173-00	NUT, hexagon	4
12	256-12156-01-00	SHAFT, rocker.....	4
13	93210-17143-00	O-RING (2.5-17.7).....	4
14	90340-18017-00	PLUG (256-11177-00)	4