




1	341-25111-01-00	HUB, front	1
2	93306-30306-00	BEARING (B6303)	1
3	93105-45017-00	OIL SEAL	1
4	93102-28022-00	OIL SEAL	1
5	93306-30307-00	BEARING (B6303)	1
6	90560-17126-00	SPACER	1
7	152-25115-00-00	FLANGE, spacer 1	1
8	341-25149-00-00	CLUTCH, meter	1
9	341-25846-00-00	RETAINER, clutch	1
10	1L9-25847-00-00	COVER, housing	1
11	94135-19389-00	TIRE (3.50-19)	1
12	94232-19122-00	TUBE (3.25-19)	1
13	94332-19085-00	BAND, rim (3.25-19)	1
14	156-25398-00-00	BALANCER, wheel	1
15	94418-19239-00	RIM (1.85-19)	1
16	3G0-25104-00-00	SPOKE SET, front	1
17	341-25190-01-00	GEAR UNIT ASS'Y	1
18	341-25181-01-00	AXLE, wheel	1
19	92901-14200-00	WASHER, plain	1
20	90171-14020-00	NUT, castle (90171-14006)	1
21	91401-30030-00	PIN, cotter	1
22	90387-17433-00	COLLAR	1
23	341-25118-00-00	COVER, hub dust	1