





No.	Number	Description	Qty.
1	584-15411-00-00	COVER, crankcase 1.....	1
2	306-15461-00-00	GASKET, crankcase cover 2	1
3	91830-22016-00	PIN, dowel	2
4	91316-06025-00	BOLT	4
5	91316-06040-00	BOLT	2
6	256-15425-00-00	COVER, generator 2	1
7	98501-05010-00	SCREW, pan head (98503-05010)	2
	98501-05010-00	SCREW, pan head (98503-05010)	2
8	256-15417-01-00	COVER, adjusting	1



* 1	99999-01146-00	COVER, crankcase 2 (256-15421-04)	1
	4E3-15421-00-00	. COVER, crankcase 2	1
	2H7-15361-00-00	. GAUGE, level	1
2	256-15451-00-00	GASKET, crankcase cover	1
3	91830-22016-00	PIN, dowel	2
4	91316-06075-00	BOLT	4
5	91316-06040-00	BOLT	1
6	91316-06025-00	BOLT	5
7	90430-06014-00	GASKET	4
8	256-15416-02-00	COVER, oil pump	1
9	256-15456-00-00	GASKET	1
10	91316-06025-00	BOLT	2

*Indicates new part numbers activated from March, 1981.