


# STARTING MOTOR UNIT



Ref. No.	Part Number	Description	Qty.
1	306-Y1554-00-00	WHEEL, starter (306-15524-00)	1
2	90501-15409-00	SPRING, compression	1
3	447-15516-00-00	GEAR 4 (23T)	1
4	90468-29062-00	CLIP	1
5	306-15515-00-00	GEAR 3 (23T)	1
6	90201-17257-00	WASHER, plate	1
7	306-15562-00-00	CLIP	2
8	306-15563-00-00	HOLDER, clip	1
9	93410-17008-00	CIRCLIP	1
10	306-15522-00-00	SHAFT 2	1
11	306-15513-00-00	GEAR 1 (24T)	1
12	306-15514-00-00	GEAR 2 (14T)	1
13	447-15531-00-00	PLATE, stopper	1
14	92503-06020-00	SCREW, pan head (92501-06020)	1
15	306-15521-00-00	SHAFT 1	1
16	306-15512-00-00	GEAR, idler 1 (36T)	1
17	306-15517-00-00	GEAR, idler 2 (26T)	1
18	306-15571-00-00	ABSORBER	6
19	306-15532-00-00	PLATE, idle gear	1
20	92503-06018-00	SCREW, pan head (92501-06018)	3
21	90387-12093-00	COLLAR	1
22	90206-12034-00	WASHER, wave	1
23	93102-34095-00	OIL SEAL	1
24	306-15431-00-00	COVER, crankcase 3	1
25	306-15452-00-00	GASKET, gear crank cover	1
26	93604-08071-00	PIN, dowel	2
27	97301-06025-00	BOLT	6