


# SEAT



Ref. No.	Part Number	Description	Qty.
1	4M4-W2472-00-00	DOUBLE SEAT ASS'Y.	1
2	4M4-24731-00-00	COVER, double seat.	1
3	3G1-24718-00-00	BRACKET, seat	1
4	1L9-24741-00-00	PAD, seat	4
5	371-27114-00-00	STOPPER, main stand	2
6	2R6-28185-00-00	LID.	1
7	3G1-24737-00-00	DAMPER, seat.	1
8	90387-06595-00	COLLAR	8
9	3G1-24748-01-00	BRACKET, seat	1
10	3G1-24738-01-00	BRACKET, seat	1
11	3G1-24754-01-00	HOOK, seat	1
12	3G1-24747-00-00	DAMPER, seat.	2
13	3G1-24724-00-00	DAMPER, seat.	2
14	95302-06600-00	NUT.	6
15	90201-06008-00	WASHER, plate	8
16	90508-19439-00	SPRING, torsion	1
17	97301-06025-00	BOLT (97302-06025)	2
18	3G1-24758-00-00	COVER, tail	1
19	92903-08200-00	WASHER, plain (92901-08200)	4
20	97301-08025-00	BOLT.	2
21	95301-08600-00	NUT.	2
22	4M4-24705-00-00	SEAT LOCK ASS'Y	1
23	90149-06154-00	SCREW.	1
24	92503-06012-00	SCREW, panhead (92501-06012)	2
25	92901-06600-00	WASHER, plate	2
26	3G1-24775-00-00	BRACKET, seat lever	1
27	3G1-24776-00-00	LEVER, seat	1
28	91401-20015-00	PIN, cotter (91401-20012)	2
29	90508-20413-00	SPRING, torsion	1