



INTAKE



Ref. No.	Part Number	Description	Qty.
1	3G1-13586-00-00	JOINT, carburetor 1	1
2	3G1-13564-00-00	COVER, manifold.....	1
3	3G1-13596-00-00	JOINT, carburetor 2	1
4	1J7-13569-00-00	PLUG, blind	1
5	90467-10039-00	CLIP	1
6	3G1-13594-00-00	COVER, manifold 2	1
7	3G1-13556-00-00	GASKET, manifold.....	2
8	91316-06020-00	BOLT.....	4
9	90460-53106-00	CLAMP, hose	2
10	3G1-14411-00-00	CASE, air cleaner 1	1
11	3G1-14451-00-00	ELEMENT, air cleaner.....	1
12	3G1-14468-00-00	PLATE, element fitting	1
13	3G1-14422-00-00	CAP, cleaner case 2	1
14	3G1-14431-00-00	SILENCER, intake 1	2
15	3G1-14452-00-00	SEAL	1
16	92503-06045-00	SCREW, panhead (92501-06045)	1
17	92901-06600-00	WASHER, plate	1
18	3G1-14453-00-00	JOINT, air cleaner 1	1
19	90506-06095-00	SPRING, tension.....	1
20	90460-64065-00	CLAMP, hose.....	1

INTAKE



Ref. No.	Part Number	Description	Qty.
21	3G1-14421-00-00	CASE, air cleaner 2	1
22	3G1-14451-00-00	ELEMENT, air cleaner	1
23	3G1-14468-00-00	PLATE, element fitting	1
24	3G1-14422-00-00	CAP, cleaner case 2	1
25	3G1-14431-00-00	SILENCER, intake 1	2
26	3G1-14452-00-00	SEAL	1
27	92503-06045-00	SCREW, panhead (92501-06045)	1
28	92901-06600-00	WASHER, plate	1
29	3G1-14453-00-00	JOINT, air cleaner 1	1
30	90506-06095-00	SPRING, tension	1
31	90460-64065-00	CLAMP, hose	1
32	3G1-14463-00-00	JOINT, air cleaner 2	1
33	93210-64297-00	O-RING	2
34	97301-06025-00	BOLT	2
35	92903-06100-00	WASHER, spring (92901-06100)	2
36	92501-06030-00	SCREW, pan head	2
37	92903-06100-00	WASHER, spring (92901-06100)	2
38	90387-07717-00	COLLAR	1
39	90387-07549-00	COLLAR	1
40	90480-14104-00	GROMMET	1