




# ELECTRICAL - 1



5V4110-2400

Ref. No.	Part Number	Description	Qty.
1	4M4-82310-60-00	IGNITION COIL ASS'Y.....	1
2	92501-06025-00	SCREW, pan head.....	2
3	92903-06100-00	WASHER, spring.....	2
4	92901-06600-00	WASHER, plate.....	2
5	256-82370-00-00	PLUG CAP ASS'Y.....	2
	512-82370-10-00	PLUG CAP ASS'Y.....	2
6	447-82110-79-00	BATTERY ASS'Y (YUASA YB14L-A2).....	1
7	LIT-82141-09-00	LABEL, battery (118-82141-09)	1
8	90445-08582-00	HOSE.....	1
9	120-82131-00-00	BAND, battery.....	1
10	3G1-82122-00-00	SEAT, battery.....	1
11	2M0-82129-00-00	COVER, battery.....	1
12	447-82115-01-00	WIRE, plus lead.....	1
13	447-82119-00-00	COVR, lead wire.....	1
14	447-82128-00-00	GROMMET.....	1
15	447-82116-00-00	WIRE, minus lead.....	1
16	97301-06012-00	BOLT.....	1
17	92903-06100-00	WASHER, spring.....	1


Battery: Model / Specific Gravity / Charge Rate	YB14L-A2 (12V14AH) / 1.28 / 1.4A
Maximum Output	14V16A @ 5000 rpm
Ignition Coil Test Gap / Primary $\Omega$ / Secondary $\Omega$	6mm / 2.5 $\Omega$ $\pm$ 10% / 11K $\Omega$ $\pm$ 20%
Pulsar Coil or Pickup Coil Color Code / $\Omega$	Org ~ Blk, Gry ~ Blk / 700 $\Omega$ $\pm$ 20%



Ref. No.	Part Number	Description	Qty.
18	4H7-82508-50-00	MAIN SWITCH ASS'Y .....	1
19	97321-06016-00	BOLT .....	2
20	92901-06600-00	WASHER (92902-06600) .....	2
21	533-82530-00-00	STOP SWITCH ASS'Y .....	1
22	3G1-82540-00-00	NEUTRAL SWITCH ASS'Y .....	1
23	90201-12790-00	WASHER, plate .....	1
24	5V4-82590-50-00	WIRE HARNESS ASS'Y .....	1
25	1A0-82151-00-00	. FUSE (12V-10A) .....	3
26	1A0-82161-00-00	. FUSE (12V-20A) .....	1
27	447-82591-00-00	BAND .....	4
28	435-13474-00-00	BAND .....	1
29	5V4-82305-10-00	IGNITOR UNIT ASS'Y .....	1
30	92501-06025-00	SCREW, pan head .....	2
31	92903-06100-00	WASHER, spring .....	2
32	90201-06067-00	WASHER, plate .....	2


5V4110-2400

# ELECTRICAL - 2



Ref. No.	Part Number	Description	Qty.
1	3G1-83350-70-00	FLASHER RELAY ASS'Y.....	1
2	2M0-83371-51-00	HORN .....	1
3	97301-08025-00	BOLT.....	2
4	92903-08100-00	WASHER, spring .....	2
5	90201-08107-00	WASHER, plate .....	2
6	3G1-85110-00-00	FRONT REFLECTOR ASS'Y.....	2
7	3G1-85127-00-00	BASE, reflector .....	2
8	98503-04014-00	SCREW, pan head (98503-04015)	2
9	92901-04600-00	WASHER, plate .....	2
10	98503-04014-00	SCREW, pan head (98503-04015)	2
11	92901-04600-00	WASHER, plate .....	2
12	1A0-83395-03-00	FLASHER CANCELLING UNIT	1
13	1T3-84308-00-00	RESERVE LIGHTING UNIT ASS'Y	1
14	92503-06018-00	SCREW, pan head.....	2
15	92903-06100-00	WASHER, spring .....	2
16	92901-06600-00	WASHER, plate .....	2
17	256-81615-00-00	WIRE, lead.....	1
18	92501-06008-00	SCREW, pan head.....	1
19	92903-06100-00	WASHER, spring.....	1

Ignition Coil Test Gap / Primary $\Omega$ / Secondary $\Omega$	6mm / 2.5 $\Omega$ $\pm$ 10% / 11K $\Omega$ $\pm$ 20%
Pulsar Coil or Pickup Coil Color Code / $\Omega$	Org ~ Blk, Gry ~ Blk / 700 $\Omega$ $\pm$ 20%



Ref. No.	Part Number	Description	Qty.
20	447-81940-10-00	STARTER SWITCH ASS'Y.....	1
21	92501-06014-00	SCREW, pan head.....	1
22	92903-06100-00	WASHER, spring.....	1
23	95301-06700-00	NUT.....	2
24	92903-06100-00	WASHER, spring.....	2
25	3G1-81960-51-00	RECTIFIER & REGULATOR ASS'Y	1
26	90109-06558-00	BOLT.....	2
27	2F0-81950-50-00	RELAY ASS'Y.....	1
28	92501-06030-00	SCREW, pan head.....	2
29	92903-06100-00	WASHER, spring.....	2
30	90201-06052-00	WASHER, plate.....	2
*31	12R-81950-00-00	STARTER CIRCUIT CUT-OFF RELAY.....	1
32	4M4-81953-00-00	STAY, relay.....	1
33	4U8-81950-00-00	SIDE STAND RELAY ASS'Y.....	1
34	5V4-82566-01-00	SWICH, side stand.....	1
35	98706-05014-00	SCREW, flat head.....	2

\*Indicates new part numbers activated from March, 1982.

Ignition Coil Test Gap / Primary $\Omega$ / Secondary $\Omega$	6mm / 2.5 $\Omega$ $\pm$ 10% / 11K $\Omega$ $\pm$ 20%
Pulser Coil or Pickup Coil Color Code / $\Omega$	Org ~ 8k, Gry ~ 8k / 700 $\Omega$ $\pm$ 20%