


Ref. No.	Part Number	Description	Qty.
1	584-15411-00-00	COVER, crankcase 1.....	1
2	306-15461-00-00	GASKET, crankcase cover 2 ....	1
3	91830-22016-00	PIN, dowel.....	2
4	91311-06025-00	BOLT.....	4
5	91311-06040-00	BOLT.....	2
6	256-15425-00-00	COVER, generator 2.....	1
7	98503-05010-00	SCREW, pan head.....	2
8	256-15417-01-00	COVER, adjusting.....	1



Ref. No.	Part Number	Description	Qty.
1	4E3-15421-00-00	COVER, crankcase 2.....	1
2	2H7-15361-00-00	GAUGE, level.....	1
3	256-15451-00-00	GASKET, crankcase cover.....	1
4	91330-22016-00	PIN, dowel.....	2
5	91311-06075-00	BOLT.....	4
6	91311-06040-00	BOLT.....	1
7	91311-06025-00	BOLT.....	5
8	90430-06014-00	GASKET.....	4
9	256-15416-02-00	COVER, oil pump.....	1
10	256-15456-00-00	GASKET.....	1
11	91311-06025-00	BOLT.....	2

