




Ref. No.	Part Number	Description	Qty.
1	341-12111-04-00	VALVE, intake	2
2	341-12121-01-00	VALVE, exhaust.....	2
3	90501-29284-00	SPRING, compression	4
4	90501-42286-00	SPRING, compression	4
5	256-12116-01-00	SEAT, valve spring.....	4
6	256-12117-02-00	RETAINER, valve spring.....	4
7	341-12118-00-00	COTTER, valve.....	8
8	341-12119-02-00	SEAL, valve stem.....	4
9	306-12151-00-00	ARM, valve rocker.....	4
10	256-12156-01-00	SHAFT, rocker 2	4
11	90149-08098-00	SCREW, valve adjusting.....	4
12	90170-08173-00	NUT.....	4
13	90340-18017-00	PLUG, straight screw	4
14	93210-17143-00	O-RING.....	4

Valve Clearance (Cold) Intake / Exhaust

0.06mm / 0.15mm